



ELECTRICAL Schematic



NOTES:

- 1) NOTATIONS IN BLACK ARE STANDARD ON ALL FLYERS
- 2) RED NOTATIONS REPRESENT FLYERS WITH 7-WAY PLUG
- 3) GREEN NOTATIONS REPRESENT FLYERS WITH 4-WAY PLUG
- 4) BLUE NOTATIONS REPRESENT FLYERS WHEN EQUIPPED WITH BRAKES
- 5) THE CONVERTER WILL ALWAYS CHARGE THE BATTERY WHETHER THE 12V DISCONNECT SWITCH IS IN EITHER THE "ON" OR "OFF" POSITIONS, BUT 12V ITEMS WILL ONLY OPERATE IF THE SWITCH IS IN THE "ON" POSITION.